


straightcurve®

Specifications

100mm Flexline™
LENGTH 2200mm | TOP THICKNESS 8mm

FINISHES



- Galvanised Steel
- Weathering Steel



Steel plate thickness 1.6mm



SOLD AS SET INCLUDING

- ✓ Connector plate (pre-attached)
- ✓ 3 x galvanised pegs



ADDITIONAL ACCESSORIES

- ✓ 500mm Corner piece (bend to desired angle)
- ✓ Hard surface fixing bracket



Installation guide

100mm Flexline™



PREPARATIONS

Level the base before you start; compacting the base is recommended. This product can be used on a sandy base as well as on compacted roadbase.

Note: This edge allows gentle sloping

CORNERS

Standard corners are available for purchase, but you can choose to make your own. Simply score a line down the back of the edge and create a sufficient opening (5-7mm) in the double folded lip at the top. Bend by hand. Placing a block of wood close to the fold improves the result.

REQUIRED FIXINGS

- ✔ 2 x Tek Screws (12G x 16mm) or
- ✔ 2 x pop rivets (4mm shaft)


HARD SURFACE FIXING

If you need to secure the edge to hard surfaces, the hard surface fixing bracket can be used. It's compatible with fixing pins or can be bolted down. (Options sold separately)


TIP

- ✔ Position whole run first to be sure it's spot on before fixing in place.
- ✔ Insert ALL fix pegs adjacent edge (3A), then work from one end to the other to fix (3B).
- ✔ One length makes a tight 70cm diameter circle.


STEP 1 - JOIN




STEP 2 - FLEX




STEP 3A - PEG




STEP 3B - FIX




PRE-MADE CORNER



MAKE CORNER - NOTCH/SCORE WITH GRINDER



TIGHT RADIUS



TIGHT RADIUS

